



LFX™ Series – Liquid Filtration Excellence Engineered for Results

LFX-CSW™ String-Wound Depth Filter Cartridges Technical Overview

Filtracore Asia's **LFX-CSW™ String-Wound Depth Filter Cartridges** are engineered for **bulk particulate control and pre-treatment** in industrial water and process streams. A controlled **helical, diamond-pattern winding** forms a **graded-porosity depth matrix** with high void volume and tortuous flow paths, distributing solids throughout the media thickness. This architecture delays surface blinding, sustains a **low, stable ΔP** , and provides **high dirt-**

holding across the service interval. Flow is **outside-to-inside** to maximise contaminant accommodation and minimise fibre migration, making LFX-CSW™ a dependable front-end barrier ahead of pleated cartridges and membranes.



The construction portfolio is designed for fit-for-purpose deployment across site chemistries and temperatures. The **standard build** uses **polypropylene yarn on a polypropylene core** for broad chemical compatibility in plant utilities and process water. For higher-temperature or higher-viscosity duties, **cotton** or **glass-fibre** yarn wound on **304/316 stainless-steel cores** increases rigidity and thermal headroom whilst preserving depth-capture behaviour. All builds are **binder-free** and inherently **self-supporting** under forward differential pressure, resisting channel formation and fibre migration.

Rating coverage aligns with mainstream wound-depth practice so trains can be staged without changing housings. **Nominal 0.5–150 μm** is available (with **core SKUs typically 1–100 μm** for most pretreatment duties). Form factors are industry-standard **2.5" OD** in **10", 20", 30", and 40"** lengths with **DOE** ends for universal housings; **SOE 222/226 (flat/fin)** options are available for sealed housings requiring positive engagement. **PP/PP** builds are typically applied to **~80 °C** in water service; temperature capability increases with **stainless-steel cores** and alternative yarns, always governed by the **lowest-rated component** (cartridge, elastomer, housing).


Depth Filtration. High Dirt-Holding. Stable, Low ΔP .

Technical Specifications


- **Filter media:** Polypropylene (standard); Cotton; Glass-fibre. Binder-free winding; outside-to-inside flow
- **Core materials:** Polypropylene (standard). 304 or 316 stainless steel available (recommended for cotton/glass-fibre or elevated-temperature duties)
- **Nominal retention ratings:** 0.5, 1, 3, 5, 10, 25, 50, 75, 100, 125, 150 μm
- **Nominal lengths:** 5", 9.75", 10", 19.5", 20", 29.25", 30", 40" (127, 248, 254, 495, 508, 743, 762, 1016 mm)
- **Outside diameter:** 2.4–2.5" (62–63 mm)
- **Inside diameter:** 1.1" (28 mm)
- **Dimensional tolerances (typical):** Length $\pm 1\%$ (or ± 3 mm, whichever larger); OD ± 1 mm; ID ± 1 mm
- **End styles / seals:** DOE (double open end) standard; SOE 222/Flat, 222/Fin, 226/Flat, 226/Fin available. Elastomers: EPDM (standard), Silicone, NBR (Buna-N), FKM (Viton®) on request
- **Operating temperature (by build):** Polypropylene to 80 °C (water service, forward flow). Cotton with stainless-steel core typically to ~160 °C; glass-fibre to ~200 °C in liquid service. Always apply the lowest-rated component (cartridge, elastomer, housing); de-rate temperature with increasing ΔP
- **pH / chemistry envelope (guidance):** Polypropylene pH 1–14 in aqueous service; Cotton not recommended for strong oxidisers or prolonged high-alkali exposure; Glass-fibre suitable for wider temperature and pH ranges – verify solvent/oxidiser levels case-by-case
- **Maximum differential pressure (per element):** 2.5 bar at 30 °C (forward, outside→inside). Reverse differential pressure not permitted for wound-depth elements
- **Recommended change-out differential pressure:** 2.4 bar per element (or per process criticality)
- **Definition of nominal rating / test method:** Nominal retention is defined by initial single-pass efficiency using ISO 12103-1 test dust (A2 Fine for $\leq 5 \mu\text{m}$; A4 Coarse for $\geq 10 \mu\text{m}$) at 25 °C; curves are typical and not an absolute retention claim. For integrity-testable or absolute retention, select LFX-CPLEAT-PP™ or sterile-grade membranes
- **Chemical compatibility:** Broad compatibility with aqueous acids/alkalis and utility waters for polypropylene builds; verify compatibility for solvents/oxidisers and select elastomers accordingly
- **Cleanliness / traceability:** Low-extractables design; each element labelled with lot/traceability code
- **Compliance:** Food-contact compliant variants available (FDA 21 CFR; EU 1935/2004 & 10/2011). Manufactured under ISO 9001 quality systems
- **Related formats:** 4.5" OD "Big Blue" wound elements are specified under LFX-CBIG-SW™



Typical Pressure Drop vs Flow¹ — LFX-CSW™ (10" element, clean water, 25 °C)



Recommended Flow Rate² – LFX-CSW™ (10" element, clean water, ΔP 0.15 bar)



¹ Clean-water values at 25 °C for a single 10" cartridge. Lines are linear fits ($\Delta P \approx m \cdot Q$) per nominal grade; values exclude housing/piping losses. ΔP increases approximately in proportion to fluid viscosity (cP) at operating temperature. For 20"/30"/40" elements, per-element $\Delta P \approx 1/2 / 1/3 / 1/4$ at the same per-element flow. Size by total system ΔP and plan change-out near -1.4 bar per element (or per process criticality). Do not exceed the lowest-rated component (cartridge, elastomer, housing).

² Water at 25 °C, $\Delta P = 0.15$ bar per single 10" element. Values are per-element recommendations for sizing and reflect typical string-wound depth performance; actual results vary with viscosity, temperature, solids loading and distribution, and housing design. For 20"/30"/40" elements, per-housing flow scales approximately 2x/3x/4x at the same per-element ΔP . Add housing and piping losses to obtain total system ΔP . For fluids with viscosity \neq water, multiply ΔP by viscosity (cP) at operating temperature. Do not exceed the lowest-rated component (cartridge, elastomer, housing).

All OEM product names are trademarks of their respective holders. Use of these names does not imply affiliation or endorsement. Images shown have been professionally enhanced for visual clarity. Actual product details and appearance may differ.



■ sales@filtracoreasia.com ■ www.filtracoreasia.com ■ +65 89-FILTER (+65 89-345837)

All information and recommendations appearing in this brochure concerning the use of products described herein are based on tests believed to be reliable. However, it is the user's responsibility to determine the suitability of such products for their own use. Since actual use is beyond our control, no guarantee, expressed or implied, is made by FiltraCore Asia regarding the effects or results of such use. FiltraCore Asia assumes no liability arising from the use of these products. This document is not to be construed as complete, as additional information may be necessary under specific conditions or due to applicable laws and regulations.

© 2025 FiltraCore Asia. All rights reserved. All trademarks and registered trademarks are the property of their respective owners.